

PROJECT SPECIFICATION





18/0229

**ETA APPROVED
WBS STONE WOOL
SILICONE SYSTEM**

Project Specification

Project Name:	The Birchway, Trefechan
System:	Wetherby Stone Wool Silicone External Wall Insulation System
Substrate:	Existing Render on Masonry
Project Height:	2 Storeys
Insulation:	100mm Stone Wool Insulation
System Finish:	HECK SHP 4S Silicone Resin Render
Technical Sales Manager:	Jonathan Gardner
Tel:	07872 007149
E-mail:	jonathan.gardner@wall-systems.co.uk
Technical Support Manager:	Dean Esposito
Tel:	07545 044669
E-mail:	dean.esposito@wall-systems.co.uk

PROJECT SPECIFICATION

Project Ref: JG_26-03534LR

Project Name: The Birchway, Trefechan

13 April 2026

Prepared By: RT

Checked By: BA

Page 3 of 23

Address List

0180651	5	The Birchway	CF48 2HA	Trefechan
0180670	9	The Birchway	CF48 2HA	Trefechan
0180698	13	The Birchway	CF48 2HA	Trefechan
0180713	17	The Birchway	CF48 2HA	Trefechan
0180722	19	The Birchway	CF48 2HA	Trefechan
0180740	23	The Birchway	CF48 2HA	Trefechan
0180787	31	The Birchway	CF48 2HA	Trefechan
0180802	35	The Birchway	CF48 2HA	Trefechan
0180849	43	The Birchway	CF48 2HA	Trefechan
0180858	45	The Birchway	CF48 2HA	Trefechan
0180894	53	The Birchway	CF48 2HA	Trefechan
0180929	57	The Birchway	CF48 2HA	Trefechan
0180956	4	The Birchway	CF48 2HA	Trefechan
0180983	10	The Birchway	CF48 2HA	Trefechan
0180992	12	The Birchway	CF48 2HA	Trefechan
0181040	22	The Birchway	CF48 2HA	Trefechan
0181096	32	The Birchway	CF48 2HA	Trefechan
0181120	38	The Birchway	CF48 2HA	Trefechan

WETHERBY WALL SYSTEMS

Wetherby Walls Systems are the UK's market leading EWI system supplier, providing quality products and systems and unrivalled technical and on-site project support. We aim to provide environmentally responsible and sustainable building products of the highest quality, continually improving on our quality and system accreditations to ensure that optimum standards are met.

WETHERBY
Wall Systems

Part of ROCKWOOL Group

WETHERBY PREMIUM CERTIFIED PRODUCTS

Wetherby Walls Systems products and EWI systems are tested to the highest level with an unrivalled range of BBA, BDA and ETA certificates available for use on projects in the UK. All testing achieves the highest European standards, ensuring long term durability, strength and premium performance. BBA/BDA approved systems provide a minimum life expectancy of 30 years. BRE Fire Certification has also been achieved for a large number of systems, with certain certification extending to 60-year life expectancy.



UK MANUFACTURING

Here at Wetherby, we take our responsibility to 'Buy British' extremely seriously. All of our current and potential suppliers undergo a rigorous annual assessment. Each supplier is reviewed over a number of areas including responsible procurement, product suitability, commitment to sustainability, quality etc. Only when we are completely satisfied are they included on our Supply Chain Database.



ISO 9001, ISO 14001, & ISO 45001

Wetherby Wall Systems have a strong pro-active approach to internal Quality Systems, Environmental Management Systems and Health and Safety. Our ISO Integrated System is regularly audited internally by qualified auditors and annually by independent external auditors, Alcumus ISOQAR. This ensures consistency in the supply and quality of our materials and services, and our environmental responsibilities and targets which we take very seriously. This includes our ongoing commitment to recycle, re-use, reduce GHG's and improve products and systems alongside our partners and suppliers. The main aim is to maximise sustainability for all products and systems across our extensive range. We have a strong pro-active approach to Health and Safety. We manage all risks associated with our activities by regularly monitoring our premises, revising Risk assessments, Safe Systems of work, and Method Statements when required. We strive to provide the best training, support, and management on all our projects providing knowledge and experience throughout the task being undertaken.



Certificate Number 16512
ISO 9001
ISO 14001
ISO 45001

TECHNICAL SERVICES

Wetherby offer a wide range of technical services to support project design and system installation. In depth NBS Specifications, project specific CAD drawings, photographic overlays, U-values and condensation / humidity risk analysis documents are all readily available via our Technical Support Team. For **Technical Enquires** please contact on **0800 1073299** or technical@wall-systems.co.uk

nbsPlus**AUTODESK®**
AUTOCAD® 2020

TRAINING SERVICES AND TRAINED APPLICATORS

We provide a variety of in-depth training courses, covering all systems, to ensure that installations are completed to the highest possible standards.

For training enquires please contact: 01942 529336.

For information on our Trained Applicators please contact your Area Sales Manager as per details on page 2 of this specification.



SITE SUPPORT, PULL OUT TESTS AND INSPECTIONS

Wetherby Wall Systems offer unrivalled site support for EWI projects with 8 Site Supervisors strategically positioned across the UK. Pull out testing, product information, detailing advice and application assistance are all available from our experienced team.



SAMPLE SERVICE

We provide a FREE sample service for all of our products and systems.

To access this service, contact our sample department on 0800 1073288 or alternatively e-mail Angela Naylor who will be more than happy to assist you with your enquiry: angela.naylor@wall-systems.co.uk



GUARANTEES

Wetherby can provide a guarantee covering defects in materials on Wetherby BBA / BDA / ETA approved EWI systems installed by Wetherby recognised contractors, for the first 10 years of the system lifespan*. Extended guarantees are available for government backed schemes provided by carefully selected third party insurance partners such as SWIGA and GDGC*. Please contact Wetherby for further information.

(*conditions apply)



CDM REGULATIONS 2015

Wetherby Wall Systems provide technical support as a supplier of façade systems and we hold the position of 'designers' according to the CDM Regulations 2015. Wetherby have a number of legal responsibilities in this role when preparing or modifying designs, to eliminate, reduce or control foreseeable risks that may arise during construction, maintenance and use of a building once built. We are also obligated to provide timely information to other members of the project team to help them fulfil their duties. Further information is contained in our CDM document (WF224) which is applicable to all designs and is available on our web site (www.wall-systems.co.uk/xpagex) or on request



PAS2035:2023

The PAS2035 design process must be followed as per the PAS document "PAS 2035:2023 Retrofitting dwellings for improved energy efficiency – Specification and guidance".

It is essential the correct surveys are completed, risk assessments are carried out and the roles and responsibilities are agreed, including a Retrofit Coordinator, taking responsibility for the specific property design.

This specification must be agreed and signed off by the project specific Retrofit Coordinator, as the PAS2035 provides a whole-house approach.

PAS 2030:2023 REQUIREMENTS

PAS 2030:2023 PRE-INSTALLATION BUILDING INSPECTION REQUIREMENTS

- Pre-installation Building Inspection Requirements
 1. To meet the requirements specified in PAS 2030:2023, the designated competent person shall confirm that:
 - a) A full and detailed pre-design building survey has been undertaken by a competent person (see B4-I3 of the PAS), prior to the retrofit design being undertaken; and
 - b) The retrofit design relevant to the installation under inspection has been produced in accordance with PAS 2030:2023, taking full account of the findings and recommendations of the pre-design building assessment, including:
 - thermal performance calculations
 - moisture risk analysis
 - ventilation requirements and standard / bespoke drawing details
 - the main components of the system including the fixing type / method, the insulation type and thickness, the joint details and specifications, the reinforcing coat and type of reinforcement and the finish;
 - the proposed details for the main interfaces; (thermal bridging, meter boxes, reveals, roofline joists, party walls, base detail with particular reference to below dpc, base/floor details, seals at windows/doors, seals to penetrations, light fittings, sockets, fixing and sealing of surface mounted structures, interfaces with ceilings, interfaces with roof, junctions between the system and other finishes and/or other EEM) clearly demonstrate how the installation will avoid condensation risk particularly at moisture sensitive locations such as embedded timbers (e.g. timber joist ends) as well as surface condensation; and
 - the installation to the retrofit design is practical and achievable given the particular EWI system chosen for the project and the specific dwelling construction, site conditions and other EEMs planned for the property. (See also the Measures Interaction matrix Figure A.1).

2. As a minimum the Retrofit Installer shall:
- investigate and assess if the EWI installation work:
 - results in non-compliance with the Building Regulations, e.g. in relation to workmanship, materials, structural stability, fire safety;
 - provides resilience to moisture. Where possible, any areas of non-compliance shall be rectified by selection of another solution/ detail, which shall be documented in the pre-installation building inspection and all contract documentation amended accordingly i.e. specification, drawings, method statement;
 - results in avoidable thermal bridging; where thermal bridging is avoidable by adaptation of the detail, such measures shall be taken and the contract documents amended to suit. Design details shall be such that they incorporate additional capacity, that for example, will provide water management within the system should surface or interstitial condensation occur;
 - results in unsafe operation of combustion appliances; unless an alternative safe detail can be found, EWI works shall not progress in the area causing the unsafe operation;
 - compromises the functionality of existing ventilation ducts/systems; unless an alternative safe detail can be found, EWI works shall not progress in the area causing the unsafe operation;
 - compromises the functionality and/or safety of existing services (gas, electric, water, telephone, etc.); unless an alternative safe detail can be found, EWI works shall not progress in the area causing the unsafe operation; and
 - results in the proposed installation being non-compliant with any requirements of the EEM supplier or of the retrofit design.
 - include confirmation that the condition of the substrate is suitable for the works to commence and where all or any of the substrate does not fulfil the requirements for installation, preparation of proposals for adaptations to be made or additional preparation undertaken that will be necessary in order that works can commence.
 - verify that all instances of potential non-compliance identified in the pre-installation building inspection shall be documented and referred to the Retrofit Coordinator for resolution. Any design adjustments, special adaptations and/or additional preparation requirements shall be confirmed as acceptable in writing, by the system supplier and/or the Retrofit Coordinator.
 - amend the retrofit design documentation to include any specified changes to the installation, the installation method statement modified accordingly and the pre-installation building inspection records updated to provide documentary evidence that the intended modified installation will address all the issues identified in the pre-installation building inspection and meets the requirements of all parties.

NOTE: In undertaking pre-installation building inspections it is recommended that Retrofit Installers use an industry recommended checklist (see PAS 2030:2023 clause 10.7.1).

3. The Retrofit Installer shall
- verify that the pre-installation building inspection has been independently checked by an appropriately qualified person (see PAS 2030:2023 clause B4-I3) prior to commencement of installation;
 - a randomly selected 1 in 10 of those checks (minimum 1) shall include physical inspection of the dwelling by a qualified person;
 - the person undertaking the independent checks and inspection shall:
 - be independent of the inspector or the Retrofit Installer of the EWI; and
 - not be paid by results nor remunerated only where an assessment is found to be valid;
- OR
- verify that a recognised pre-notification process has been undertaken under an industry quality assurance scheme for external wall insulation, that has the features listed in B.1 of PAS 2035:2023.
4. The Retrofit Installer shall confirm that each inspection checked includes a unique identifier and the names of the persons who completed the inspection and the check.

PAS 2030:2023 ADDITIONAL INSTALLATION REQUIREMENTS

Due to the high risk of thermal by-pass rendering the insulation ineffective, external wall insulation shall not be installed on walls of cavity construction that have unfilled cavities or have had cavity wall insulation removed and not replaced, unless the cavities have been sealed in accordance with the specifications and construction details provided by the Retrofit Designer (see PAS 2035:2023 for further details).

The Retrofit Installer shall use methods of installation specified by the system supplier (where provided) and in accordance with the relevant retrofit design. This information shall be included in the installation method statement. In undertaking the installation, the Retrofit Installer's responsibilities shall include:

- a) Before installation starts, confirming that the retrofit design has made provision for:
- the EWI system provided for installation is that recommended by the pre-design building survey and specified by the retrofit design;
 - wind loads have been calculated and taken into account in the fixing requirements;
 - all essential ventilation openings that require sleeving or safeguarding before installation are located and identified;
 - the position of all flues whether or not they are in service is determined and the measures that shall be taken to safeguard their proper functioning is determined;
 - any existing cables, pipework, ducting etc. that require it are removed or repositioned as/where necessary to accommodate the planned EWI system, with authorization from the relevant responsible body (where required) and undertaken by a person competent to undertake such work; the existing ground levels, paths or decking adjacent to the dwelling are 150 mm below the level of the damp proof course; and
 - other areas of the dwelling and surrounding area that could be at risk during installation are adequately protected to ensure they are not damaged; and in the event that any of these aspects is not adequately covered, liaising with the Retrofit Designer to provide for their undertaking.

b) During installation, verifying that:

- all work is carried out in accordance with the site-specific retrofit design, drawings and method statement and that work is not permitted to progress unless copies of the site-specific specification documentation are accessible at location and all operatives are aware of the content and requirements relevant to their designated activities;
 - the system and all detailed interfaces with other parts of the dwelling or other planned EEMs to be undertaken in a manner and sequenced such, that all measures are fully effective, with optimized performance and junctions that are safe, durable and fully weatherproof for all expected exposure conditions. e.g. interface between EWI system and planned replacement windows; and
 - whether or not specifically required by the retrofit design, the items listed in **i) to viii)** below are given particular attention with regard to the efficacy and durability of the detail especially concerning the management and exclusion of moisture and/or the risk of surface/interstitial condensation or rising damp. Mastic sealants shall always be supported by a primary seal below, and all details shall be fully weatherproof:
 - i. system base detail (including below dpc);
 - ii. interfaces with roofs at eaves and verges (where metal or plastic cappings and trims shall not be used); unless these are detailed within the document External Wall Insulation Specification for Weathering and Thermal Bridge Control [N2] (PAS 2030:2023 clause 10.7.1);
 - iii. window/door reveals/heads;
 - iv. system/cill interfaces (incl. overhang requirements/weepholes/thermal movement);
 - v. surface fixtures (structurally sound);
 - vi. penetrations through the system;
 - vii. interfaces with roof soffits, flat roofs, conservatory roofs etc.; and
 - viii. detailing and sealing around vents/flues, meters and other heating related structures/pipework.
- PLEASE REFER TO WETHERBY DETAIL DRAWINGS FOR GUIDANCE

- all weather seals at the interface between EWI systems and other structures/finishes are installed with particular attention given to the soundness/cleanliness of contact surfaces, continuity and effectiveness around corners, bond to surfaces and the durability of the water seal;
- all details are installed to minimize the risks of thermal bridging, removing/relocating/extending to allow continuity of insulation in all cases e.g. rooflines, meter boxes, pipework, flues, ducts;
- photographic evidence of key stages of the installation is prepared and retained for the period of the guarantee, including close up photographs of representative examples of all moisture and thermally sensitive details; installations are undertaken in accordance with the specification for the installation of external wall insulation ensuring the safety and operation of fuel burning appliances, taking account of the recommendations provided in the document External Wall Insulation Specification for Weathering and Thermal Bridge Control [N2] (see PAS 2030:2023 clause 10.7.1);
- ventilation of the dwelling is assessed and if necessary upgraded in accordance with the retrofit design and with the requirements of PAS 2035:2023; and
- upon completion of the installation or at the end of each working day, if the installation takes longer than one day, the operatives investigate and confirm the proper functioning of all ventilation openings and flues.

NOTE 1 Attention is drawn to the requirements for installation methods to be included under current certification issued by a product certification body, with respect to the product/system to be installed, against UK requirements and regulation and the Retrofit Installer should be aware that training from the supplier or training acceptable to the supplier is necessary before an application for assessment/certification is made to a certification body.

NOTE 2 Attention is drawn to the need, where relevant, for all external wall insulation installation work to comply with the current Building Regulations that apply in the UK country in which the installation is being carried out. In particular, the need for compliance in relation to the following aspects is highlighted: fire safety; resistance to moisture; ventilation; and conservation of fuel and power. Further guidance on the requirements of the Building Regulations in England is provided in Approved Documents A-S [6] and Regulation 7: Workmanship and Materials [7]. Further guidance on the requirements of the Building Regulations in Wales is provided in Approved Documents A-R [8] and guidance on Regulation 7: Workmanship and Materials [7]. Further guidance on the requirements of the Building Regulations in Scotland is provided in the Domestic Technical Handbook [9] and Non-Domestic Technical Handbook [10].

PAS 2030:2023 RETROFIT INSTALLER COMPETENCE RATIO

For each installation task to be undertaken, the Retrofit Installer shall employ or subcontract at the particular location, at least one vocationally competent operative. For each installation, the vocational competence ratio (see PAS 2030:2023 3.29) shall be determined by the Retrofit Installer in relation to the:

- a) range, scale, geographical spread and complexity of the work being undertaken; and
- b) supervision and experience of the individual that meets the vocational competence requirements for the relevant tasks and the relative experience of the operatives being supervised;

but shall not be less than one carded operative per team of 4 (1 to 3), at the specified installation location at any time.

NOTE 1 Where a vocationally competent operative is newly qualified, it may be appropriate for a lower competency ratio to be applied.

For each installation task to be undertaken at a particular location, supervision, inspection and confirmation of compliance of all work undertaken in respect of that task at that location shall be undertaken by a vocationally competent operative appointed by the Retrofit Installer to do so.

NOTE 2 It is recommended that vocationally competent operatives carry a document supporting the nature, currency and source of that competency, for production upon request.

PAS 2030:2023 MEASURE SPECIFIC INFORMATION TO BE HANDED OVER TO THE CLIENT

- The user manual shall include details on fixing to the system, drilling or cutting the system, repairs to damaged areas, avoiding damage (e.g. ladders), cleaning recommendations, importance of weather seals, name/contact details of both the Installer and system certificate holder, materials specification (name, colours, etc.) and guidance on living in a highly insulated property, including the need for appropriate ventilation. The contents of the manual shall be explained to the client (not just left with them).
- Where end-user maintenance is possible, details of how to undertake the maintenance including frequency and any product or tools that shall be used and where to obtain the required products and tools.
- Building Regulations compliance certificate (or information explaining that a Building Regulations compliance certificate is required and will be provided within 30 days).
- It shall be explained to the client that repairs should be carried out by a competent person, but that maintenance is their responsibility.
- Any relevant product warranty information and guarantees shall be included in handover.

WETHERBY STONE WOOL SILICONE SPECIFICATION**M21****Insulation with rendered finish**

To be read with Preliminaries/General Conditions.

This specification is valid for 6 months from issue date, due to the changing industry regulations and requirements.

For an updated version of the specification please contact the relevant technical sales manager.

This specification is specifically for the named project and is not transferable to other projects, projects require specific custom specifications, please contact Wetherby Technical departments for further information

GENERAL / SYSTEM REQUIREMENTS**120 SURVEY OF EXISTING WALLS**

- Timing: Before starting work covered in this section.
- Objective: To confirm suitability for application of external wall insulation system.
- Survey report: Submit, covering all relevant matters listed below:
 - The form and condition of the structural substrate.
 - A schedule of repairs and / or additional works necessary to render the substrate suitable to receive the system.
 - A schedule of services, fixtures and fittings requiring removal to facilitate installation of the system.
 - Proposals for treatment of potential cold bridges e.g. reveals, concrete floor edges.
 - Remove existing rainwater pipes and re-direct away from work surface whilst work proceeds. Ensure all rainwater from the roof area is carried away from the work area by means of temporary fixed rainwater goods.
 - Remove, extend beyond the surface of the proposed system and securely re-fix, to the satisfaction of the supervising officer, soil stacks, waste water pipes, overflows, vent pipes etc.
 - Any other information considered relevant.

150 WIND LOADING

- When installed on suitable walls, the system can adequately transfer to the wall the self-weight and negative (suction) and positive (pressure) wind loads normally experienced in the United Kingdom.
- Wetherby or the fixing manufacturer will undertake fixing pull out tests on site to verify the adequacy of the fixings.
- Wetherby will provide information on the system dead load weights on request to allow an independent check to be made of the substrates adequate strength and suitability.
- On projects where higher wind load coefficients are expected, wind load calculations are required in order to establish the minimum number of fixings required per m² to resist the maximum wind loads acting on the building. In order to do this, wind loads must be calculated by a suitably qualified and experienced structural engineer in accordance with BS EN 1991-1-4:2005 and provided to Wetherby. Wetherby will then confirm an adequate fixing pattern for the project.

160 REMEDIAL WORK


- Remedial work shown to be necessary by survey: Employer's responsibility.

180 STRUCTURAL SUBSTRATE

- Description: Existing Render on Masonry.
- Preparation:
 - Treatment to Existing Sound Surfaces
Remove any existing loose material and where required dub out the surface level, ready to receive the EWI system. The existing walls are to be cleaned with a wire brush or pressure jet wash, to the satisfaction of the Contract Administrator, to remove any friable material, algae or lichen, and to provide a good key for Wetherby products. Treat areas of moss, algae and mould growth with Wetherby Biocidal Wash. Dense smooth surfaces may require treating with Wetherby Stabilising Solution / Bonding Agent to ensure adequate adhesion on wet fix or render only applications.
 - If the walls include existing render or the substrate isn't line and level and requires dubbing out, the fixing lengths stated within this specification may need to change. This will need to be confirmed on site prior to the installation of the Wetherby system. Sizing of flashings, trims and beads may also require alterations.
 - Dubbing Out
Where necessary dub out, using Wetherby Dubbing Render, any hollow / defective areas to leave a suitable surface for the application of the insulation boards. Maximum dubbing coat thickness: 16mm.
 - Biocidal Wash
Where required, apply one coat of Wetherby Biocidal Wash to the entire surface by roller or knapsack spray and allow to dry. Brush the surface to remove all signs of growth before rendering commences.
 - Stabilising Solution
Where required, apply one coat of Wetherby Stabilising Solution to the entire surface by roller, ensuring uniform coverage and allow to dry.

210A EXTERNAL WALL INSULATION SYSTEM

- **Manufacturer:**
Wetherby Wall Systems Ltd.
1 Kid Glove Road
Golborne Enterprise Park
Golborne
Greater Manchester
WA3 3GS
Tel: 01942 717100
Fax: 01942 717101
Email: info@Wetherby-ltd.co.uk
Web: www.Wetherby-ltd.co.uk
- System Reference: **Wetherby Stone Wool Silicone External Wall Insulation System.**



- Insulation: Wetherby Stone Wool Insulation Boards.
(Rockwool External Wall Dual Density Slab).
 - Thickness: 100mm.
 - Board Size: 1200 x 600mm.
 - Minimum Compressive Strength: 10 kPa.
 - Thermal Conductivity: 0.036 Wm²/K.
 - Performance in Relation to Fire:
 - Class A1 (BS EN 13501-1:2002).
 - Non-combustible.
 - Environmental:
 - CFC / HCFC Free.
 - Zero ODP.
 - GWP Less Than 5.

- Fixing: Mechanical and Adhesive.
 - Insulation Adhesive: Wetherby Insulation Bedding Adhesive.
 - Fixing Type: TFIX-8M x 155mm (subject to pull out tests).
 - Fixing Retaining Plate: 90mm Insulation Washer.
 - Fixings must achieve a minimum pull out of 1.0kN.
- Insulation to Reveals: Stone Wool Insulation Board.
 - Thickness: 30mm.
 - Fixing: ISO 45/65 x 95mm.
- Below DPC (Where Required).
 - Insulation Type: HD EPS Insulation Board.
 - Thickness: 80mm.
 - Fixing Type: TFIX-8M x 135mm.
 - Bedding Coat: Wetherbycoat brush applied at 2mm to bottom of basetrack, substrate and bottom of insulation board.
 - Reinforcing Coat: HECK K+A Scrim Adhesive applied 6-8mm and reinforced with alkali resistant glass fibre reinforcing mesh.
 - Decorative Finish: TBC.
- Protective Scrim Adhesive Coat (If Required).
 - Reinforcement Adhesive: HECK K+A Scrim Adhesive.
 - All board edgers must be protected to prevent water ingress into the Stone Wool insulation.
 - Where boards are to be left exposed, 1-2mm tight coat to be applied over all Stone Wool Insulation on the day of the board being fixed, ensuring all Stone Wool Insulation is coated and protected from moisture.
 - Stone Wool insulation must be fully dry before basecoat is applied.
- Movement Joints: As Per Drawings.
 - Vertical Movement Joint Ref: Wetherby MJ6 Movement Joint.
 - Horizontal Movement Joint Ref: Wetherby RCJT & RCJB Horizontal Compression joint.
 - Movement joints must be used to replicate any structural movement in the existing substrate to be adequately designed for the building's movement as per site survey / Structural Engineers report.
 - All beads must be fully meshed in.
 - Refer to clause 490 for further information and guidance.
- Reinforcement: Alkali Resistant Reinforcing Scrim Cloth incorporated into top third of the HECK K+A Scrim Adhesive.
 - Reinforcement Adhesive: HECK K+A Scrim Adhesive.
 - Secondary mechanical fixings are required on all projects 2 storeys and above as per BRE Report BR135:2013.
 - NHBC require in all cases that a minimum of one non-combustible fixing is installed through the reinforcement mesh per insulation board, in addition to other fixings.
 - Secondary fixing requirements to be confirmed by local building control.
- Decorative Finish.
 - Wetherby Primer: HECK UG Universal Primer (colour to match the finish coat).
 - Wetherby Finish Coat: HECK SHP 4S Silicone Resin Render.
 - Colour: TBC.

- Additional Coating.
 - Wetherby Render Protector: Apply one clear coat of Render Protector.
- Beads / Trims / Accessories.
 - Full System Beads / Trims:
 - Wetherby Starter Track Ref: Wetherby 9150 (90610) 100mm Aluminium Base Rail with Wetherby 37400 Profile Clip.
 - Wetherby Full Depth Stop Bead Ref: Wetherby 9250 (93310) 100mm Aluminium Full System Stop Profile.
 - Mechanical Fixing: Wetherby HIT 6/5 Hammerscrew Bead Fixing.
 - Wetherby Roof Detail: TBC.
 - Specialist flashing or Wetherby 781 type trim to be used subject to roof design, ensuring a minimum 40mm overhang and a long-lasting watertight detail (approval required from Wetherby).
 - The top of the system must be protected at all times during installation, using temporary capping protection where required.
 - Aluminium Overcill (if required)
Wetherby Aluminium Overcills. All cills shall be site measured (ensuring a minimum 40mm overhang) and supplied with welded end caps to suit the application.
 - Aluminium Undercill Extenders (if required).
 - All cills and flashings must provide a minimum 40mm overhang to protect the Wetherby System
 - Surface Render System Beads:
 - Wetherby Corner Bead Ref: Wetherby 3707 PVC Corner Bead.
 - Wetherby Render Bellcast Bead Ref: Wetherby B10 PVC Bellcast Bead.
 - Wetherby Render Stop Bead Ref: Wetherby RS6 PVC Stop Bead.
 - Wetherby Vertical Movement Joint Ref: Wetherby MJ6 PVC Movement Joint.
 - Wetherby Horizontal Movement Joint Ref: RCJT & RCJB Horizontal Compression Joint.
 - Wetherby APU Frame Seal Ref: Wetherby APU 37909 PVC Frame Seal.
- Accessories:
 - Wetherby Sealing Tape: Pre-compressed, expanding waterproof sealing tape.
 - Wetherby Firtree Fixings.
 - Wetherby Approved Silicone Sealant.

N.B. Beads / trims may need to be altered depending on site inspections and job specific detailing / application.

310 DESIGN

- Complete the detailed design of system and associated features shown on drawings:
Complete to meet requirements of this specification. Refer to Wetherby detail drawings.
- Please note all compliance needed to meet Building and Fire Regulations is the responsibility of the principle designer/ main contractor.
- Detailing of system junctions & ancillary items are to be agreed by all parties.

320 INTEGRITY

- Installation Requirements:
 - Weathertight under all anticipated conditions.
 - Capable of resisting all dead loads and design live loads, including impact and wind loads, and accommodating all thermal movements without damage.

330 IMPACT LOADING

- Impact Resistance of Finished Walls: Resistance to hard body impacts (3 joules to 10 joules) and to perforation.

340 WIND LOADING

- Design Wind Loads: The system shall be designed to withstand all design wind loads.

360 SAMPLES

- Procedure: Submit samples / examples of designated items for approval. Keep approved samples on site for the duration of the contract for inspection / comparison purposes.
- Designated items: Textured sample of HECK SHP 4S Silicone Resin Render.

370 UNIFORMITY OF COLOUR AND TEXTURE

- Type / proportion of constituent materials: Unchanged once samples of coatings have been approved.
- Supplies of materials: Sufficient to give consistent and uniform colour and texture.
- All materials shall be manufactured and supplied in accordance with BS EN ISO 9001: 2008.
- Wetherby renders and mortars are pre-blended during the manufacturing process by the supplier, although care should be taken to ensure colour uniformity between individual batches of material.

380 LIGHTNESS

- It is advised that Silicone Textured Render Systems for application over insulated render backgrounds shall be selected in colour(s) with a lightness factor of >20. Should the lightness factor of the selected colour(s) be <20, please contact the Wetherby Technical Support Team for further information.

390 AVOIDANCE OF COLOUR SHADING

- To minimise the risk of variations in colour shade and to avoid dry line jointing, decorative finishes should be applied continuously without a break.
- Where breaks are unavoidable, they should be made where services or architectural features such as the lines of doors, windows, reveals or drainpipes help to conceal the position of the joint. Surface render beads can be used to provide a clean break in the render.
- Material sharing the same batch number should be used to complete an entire elevation where possible.
- Material with different batch numbers should be checked for colour consistency.

410A INSTALLATION

- Installer: The system shall be installed by a specialist contractor approved for the project by Wetherby Building Systems.

415A WETHERBY STONE WOOL 4S SILICONE SYSTEM APPLICATION PAS2030:2023**Base Bead**

Securely fix Wetherby starter track with profile clip above DPC level at base of the system. Mechanically fix starter track at max. 300mm centres, 50mm from each end. Wetherby 3756 base rail connectors should be used to join the tracks, packing shims may be required to ensure the starter track is true to line and level. Any gaps behind the basetrack allowing free air movement behind the insulation should be sealed appropriately.

Full System Stop Bead

Securely fix Wetherby full system stop beads on Wetherby Sealing Tape to the extent of the system and its abutment to untreated areas i.e. meter boxes, rising service supplies or any other untreated abutment. Stop beads are to be fixed at max. 300mm centres, 50mm from each end. A continuous bead of Wetherby Approved Silicone Sealant must be applied to seal the stop bead to the substrate.

Roofline Closure System: Where Required

For guidance on application of the Roofline Closure Systems, please refer to our Roof Line Closure system guide. Project specific solutions must be agreed in line with Wetherby Detail Drawings and PAS 2030:2023 Guidance.

Where the existing roof does not provide an adequate overhang to the EWI system (minimum 40mm), a specialist roofing profile or flashing must be installed to provide adequate protection. All flashings must be correctly jointed and fixed, ensuring no weak points or potential areas for water ingress. Where required, temporary capping protection must be provided to protect the insulation from moisture until flashings / roof trims are in place. The EWI system must be sealed to the roofing profile using Wetherby Sealing Tape and Silicone Sealant.

Cills

Securely fix cills, ensuring they are secure and provide a water tight detail to protect the EWI system. Sealing tape & silicone sealant are required where the EWI system abuts the cill. Install end caps and apply Wetherby Approved Silicone Sealant where required.

Wetherby Insulation Bedding Adhesive – (Minimum 40%)

Wetherby Bedding Adhesive should be applied in a continuous line around the perimeter of the board with 3 additional dabs of adhesive distributed uniformly over the remaining surface. At least 40% of the board should be covered. The boards should be fully bedded into the adhesive and the initial mechanical fixings (frequency as per the fixing pattern located at the back of the specification) should be installed in each board to hold in place whilst the adhesive dries. Alternatively, apply Wetherby Insulation Bedding Adhesive to the entire face of the insulation boards using a 10mm minimum notched trowel ensuring a full spread of adhesive.

Application of Stone Wool Insulation Boards

Position and securely fix the Stone Wool insulation boards to the substrate. The boards should be tightly butt jointed, laid with staggered joints and overlapped at building corners. Board joints should not occur within 200mm of the corners of openings. Board pieces narrower than 200mm shall not be used. Where the insulation butts up against dissimilar materials, supply and install Wetherby Sealing Tape and ensure the boards are fitted tight against the seal, ensuring full compression of the tape.

N.B. thinner insulation may be required in passageways and to window reveals.



Fixing Of Insulation Boards

Fix boards mechanically to the substrate using approved Wetherby fixings at a rate of 8 - 9 per m² in accordance with Wetherby fixing pattern (fixing pattern located at the back of this document subject to pull-out / wind load calculations). Fixings shall be installed so that the fixing head embeds 1-2mm in to the face of the insulation board surface. Additional fixings should be installed to ensure a maximum of 300mm centres at either side of building corners and around all openings.

Protective Scrim Adhesive Coat (If Required)

Apply a protective scrim coat at 1-2mm where required to prevent water ingress into the Stone Wool insulation. The board edges must be protected to ensure no water ingress into the Stone Wool insulation. Where boards are to be left exposed, a 1-2mm tight coat is to be applied over the face of the Stone Wool Insulation. The insulation must be fully dry before basecoat is applied.

Movement Bead / Slip Joints

Fix movement beads / slip joints at agreed locations using Wetherby approved fixings. Structural movement joints must be mirrored through the EWl system.

Surface Mounted Render Beads

Fix surface mounted render beads directly to the insulation board at required locations using Wetherby Firtree Fixings.

Existing Air Vents, Grilles etc.

Identify live or used air vents, grilles etc. and extend through the insulation system as work progresses.

PVC Angle Bead

Fix by bedding into first pass of scrim adhesive, PVC angle beads with glassfibre mesh reference Wetherby 3707 to all external building corners, window / door jambs and heads.

APU Beads (where required)

Install APU beads around openings where required. Beads must be applied to a clean surface to ensure optimum adhesion.

HECK K+A and Alkali Resistant Reinforcing Scrim Cloth

Trowel apply a nominal 6mm thick coat of scrim adhesive to the entire surface of the insulation boards. Lightly run a notched trowel through the scrim adhesive at a 45 degree angle to ensure the correct thickness of adhesive is applied. Bed Alkali Reinforcing Scrim Cloth into top third of the wet adhesive, overlapping joints by 75mm minimum. The scrim cloth must be overlapped around building corners and returned into all reveals and heads. All beads must be fully scrimmed in. Install additional 250mm x 300mm minimum pieces of scrim cloth diagonally across corners of all wall openings. Install secondary fixings through the wet scrim adhesive and alkali resistant scrim cloth whilst adhesive is wet. 100mm x 100mm scrim patches to be installed over each secondary fixing head. Finally smooth out scrim adhesive using a spatula.

**Scrim Adhesive Coat (Second Application)**

When initial layer of scrim adhesive has hardened, trowel apply a further 2-3mm coat of scrim adhesive ensuring all alkali resistant mesh is covered. Level the scrim adhesive using a spatula / damp sponge float to achieve a uniform flat and even surface ready to receive the final finish. Allow sufficient drying time before applying the Wetherby Primer.

Allow sufficient drying time before applying the Primer. Cold conditions and high humidity will result in the basecoat taking longer to dry / cure. The basecoat must be fully hardened with no signs of moisture visible. Moisture trapped in the basecoat can potentially damage the curing of the Primer / Silicone Render causing failure after completion of the system.

HECK UG Universal Primer

Apply HECK UG Universal Primer with a brush or lamb's wool roller as per manufacturer's printed instructions. Allow the primer to fully dry, minimum 12 hours.

HECK SHP 4S Silicone Resin Render

Mix and apply HECK SHP 4S Silicone Resin Render strictly in accordance with the manufacturer's printed instructions. The top coat should be applied with a stainless steel trowel to the thickness of the grain and finished with a plastic float. Apply in a continuous application always working to a wet edge and in the same direction to ensure consistency of finish. Wherever possible, entire elevations should be completed in a single operation to avoid joint marks in the finish. This can often be achieved by working to natural breaks in the building or working to breaks in colour or texture.

Do not apply HECK SHP 4S Silicone Resin Render with differing batch numbers on the same elevation. Care should be taken to avoid texture changes at different levels. Prior to setting, polish render with plastic float to give an even texture and remove all trowel marks.



Silicone Sealant

Gun apply a continuous bead of Wetherby Approved Silicone Sealant at points where the renders will butt up against other materials, e.g. window frames, door frames, eaves, fascia's, projecting wall vents, gas and electric meter boxes etc. ensuring water tightness. Surfaces must be clean and suitable for the application of the Silicone Sealant which must be installed as per manufacturers guidance.

Render Protector

Apply Wetherby Render Protector with a roller ensuring a full and even coverage, covering 100% of the substrate. The substrate must be fully dry and clean before application; ensuring morning dew is not present on the substrate. Cross hatch application is recommended to ensure all areas are fully treated. Do not dilute product and protect from rain for a minimum 12 hours after application to allow coating to fully dry.

Cleaning

Wipe clean all exposed PVC nosing, cills etc., at each work stage whilst render is still wet.

Application Videos

Wetherby have detailed application videos available online, please see <http://www.Wetherby-ltd.co.uk/videos/>.

420**ADVERSE WEATHER**

- Materials / Surfaces: Do not use frozen materials and do not apply materials to frost bound substrates.
- Adhesives / Mortars / Renders: Do not apply when air temperature is at or below 5°C. Render products may be applied where temperatures are above 3°C on a rising thermometer and are forecast to stay above 5°C for an extended period on the same day.
- Adhesives / Mortars / Renders: Do not apply when relative humidity is equal to or greater than 90%.
- Do not apply materials when the air temperature or wall surface is in excess of 30°C without protection of the surface.
- Temperature of the work: Maintained above minimum level recommended by manufacturer until adhesive / mortar / render has fully hardened.
- Drying Times: Drying times of decorative finishes, particularly pre-mixed water based materials, may be greatly extended during periods of low temperature and / or high relative humidity 90% and above.
- Newly rendered surfaces: Protect newly rendered surfaces against rain, snow or other precipitation. Ensure that material is protected from frost, wash-offs etc.
- Application of renders, mortars or decorative finishes shall not be carried out on elevations where summer strength sunlight is hitting the area square on for prolonged periods without affording protection.
- Coatings damaged by rain or frost: Remove and replace.

440**ON SITE PULL OUT TESTS ON FIXING PINS**

- Objective: To prove suitability of structural substrate and determine size and number of fixings required.

490**CONSTRUCTION / MOVEMENT JOINTS / SLIP JOINTS**

- Location: As shown on drawings.
- Formation: Accurately to detail.
- Modifications to joint locations / design: Agree revisions before proceeding.
- All structural movement joints must be mirrored through the EWI system.
- Where the system is to be continued over joints between dissimilar substrates which are in the same plane, a movement joint should be incorporated to allow for differential movement.

500 FLUES, CHIMNEYS AND COMBUSTION AIR VENTILATORS

Reference to be made to CIGA's Technician's Best Practice Guide to Flues, Chimneys and Combustion Air Ventilators, or to the Specification of External Wall Insulation ensuring the Safety and Operation of Fuel Burning Appliances, so that the performance and safety of fuel burning appliances is not compromised by the installation of the EWI measure.

- The combustion air supply must be isolated and air ventilator continuously sleeved through the wall.
- Flueless gas fires require a ventilator that provides a free air area of 10,000 mm². Under PAS 2030, both surveyor and installer have strict responsibilities placed upon them when it comes to the identification and safeguarding of essential ventilation requirements. Failure to comply will result in PAS 2030 being revoked. Please refer to Wetherby document **Wetherby-VENTINFO-01**.

With regards to gas flues there are two methods of installation, either a clear gap is left around the flue (300mm for fanned draught flues / 600mm for natural draught flues) or a 200mm non-combustible insulation slab installed around an extended flue. While Wetherby includes both alternatives in their detail drawings, main contractors and installers must ensure the chosen method is approved in conjunction with the boiler manufacturer's specification.

515 LIGHTNING CONDUCTOR

- Should be relocated to the surface of the system or fix Stone Wool insulation strip around the lightning conductor. Notch the back of the insulation board to allow for movement of lightning conductor leaving a 10mm gap as per Wetherby detail drawing.

520 SUPPORTS FOR SERVICES / FITTINGS

- Supports for soil and rainwater pipes, signs, CCTV cameras etc: Provide in locations shown on the drawings.
- Type: timber pattresses same thickness as the insulation, fixed back to the load-bearing background using proprietary countersunk stainless steel screws or other non-corrodible fixings. Timber pattress to be no more than 200mm x 200mm.
- No load is to be transferred to the insulated render system.
- Alternatively, sleeved fixings shall be installed into the load-bearing background after completion of the render works in accordance with Wetherby recommendations.

528 EXTERNAL POWER CABLES

- External power cables must not be covered over by the EWI system or cover plates in any circumstances. Power cables must be relocated, left open and visible or suitably & safely enclosed with guidance from the power distribution authority.

530 SEALANT JOINTS

- Sealant: Wetherby Approved Silicone Sealant.
- Joints: Formed in accordance with section Z22 and system manufacturer's recommendations using any necessary joint fillers, backing strips etc.
- Sealant should be regularly checked and replaced as required. Sealant is not covered as part of the Wetherby system warranty.

540 STORAGE OF MATERIALS

- Adequate dry weatherproof and ventilated storage shall be provided for materials.
- All materials shall be protected against frost.
- Insulation boards must be kept dry at all times.
- Cementitious products shall be stored off the floor.
- Renders to be stored in temperatures of at least 5°C.
- Materials should be protected from prolonged exposure to sunlight.

550 INSPECTION OF COMPLETED INSTALLATION

- Timing: As soon as possible after completion of the work and before removing scaffolding.
- Notice for inspection (minimum): 7 working days.
- Defects: Report immediately.

570 MATERIALS AND SITE CONDITIONS

- All materials shall be provided for the proper and efficient execution and completion of the works.
- Materials shall be mixed, applied and fixed in accordance with the relevant clauses of the specification and the manufacturer's instructions.
- A clean, fresh supply of water shall be provided for the works, via the management contractor.
- Suitable scaffolding that has a minimum gap of 300mm (all scaffold items) from the elevation surface in order to facilitate application requirements, shall be provided, erected, maintained and later removed for the proper and efficient execution and completion of the works.
- All necessary temporary supports for drains, water pipes, gas pipes, electrical cables and telephone cables shall be provided and maintained until the permanent supports are reinstated.
- Temporary flexible tubing shall be provided for the efficient discharge of rainwater from the buildings to protect the system during the progress of the works.

580 CLEANLINESS OF WORKS

- Protect all existing works, approaches and adjacent surfaces including windows and doors etc. using suitable sheeting, boards, covers etc.
- Remove all splashes, droppings etc. from completed works immediately and before drying takes place.


590 CONTROL OF POLLUTION

- All debris and rubbish arising from the works shall be removed off site from time to time to keep the site and works clean and tidy. All measures shall be taken to control the noise levels produced by the operatives on site to comply with the Control of Pollution Act. Precautions should be taken to prevent pollution of any river watercourse, reservoir, drainage or the like by the operatives on site.

600 MAINTENANCE

- An initial inspection should be made within 12 months and regularly thereafter to include:
 - visual inspection of the render for signs of damage. Cracks in the render exceeding 0.2 mm must be repaired. Impact damage must be repaired to prevent moisture ingress into the system.
 - visual inspection of architectural details designed to shed water to confirm that they are performing properly.
 - visual inspection to ensure that water is not leaking from external downpipes or gutters, as such leakage could stain or penetrate the rendering.
 - Sealant joints at window and door frames, etc which must be replaced as required. Sealant is not covered as part of the Wetherby warranty.
- Maintenance schedules must be created and maintained for the building, which should include any repairs undertaken and the replacement and resealing of joints (for example, between the insulation system and window and door frame).
- The render may become discoloured with time, the rate depending on the initial colour, the degree of exposure and atmospheric pollution, as well as the design and detailing of the wall. In common with traditional renders, discoloration by algae and lichens may occur in wet areas and can be removed simply with a biocidal wash.
- Damaged areas must be repaired using the appropriate components and procedures detailed in the Certificate holder's installation instructions and in accordance with BS EN 13914-1: 2005. Please see Wetherby O&M Manual and Wetherby Maintenance Information for further details.

Wetherby EWI Fixing Pattern (Subject to Pull Out Tests & Wind-Load Calculations)



WBS Approved Mechanical Fixings, installed through insulation layer.



Additional WBS Approved Mechanical Fixings, installed at max. 300mm centres around all openings and external corners.